




## Electrical Quick Start Guide

DC Power w/Pulse, 4-20mA, & Digital (D1G/D2G) for: iMAG 4700p / AG3000p

## Wiring

On the back of the meter, unscrew the black user access lid and remove it. Remove the 15 pin screw connector from its bag. Install the wires through the cable ports into the 15 pin screw connector in their respective locations. Plug the 15 pin screw connector into its socket. **Be sure all pins align properly and that the connector has not slipped to one side.** Refer to the complete manual for further details. (C1 = power/output cable 1, C2 = power/output cable 2)



Refer to the *Mechanical Quick Start Guide* or the complete instruction manual for details on mechanical installation.



## **Electrical Quick Start Guide**

DC Power w/Pulse, 4-20mA, & Digital (D1G/D2G) for: iMAG 4700p / AG3000p

